
Total Indicator Run Out



Screw to barrel contact shown by arrows.

